




DRIVE SPROCKET AND EXHAUST PIPE/MUFFLER



Order	Job name/Part name	Q'ty	Remarks
	Drive sprocket and exhaust pipe/muffler removal		Remove the parts in the order below.
	Air filter case		Refer to "AIR FILTER CASE" in CHAPTER 3.
	Carburetor assembly		Refer to "CARBURETOR" in CHAPTER 6.
	Radiator assembly		Refer to "RADIATOR" in CHAPTER 5.
	Thermostatic valve assembly		Refer to "THERMOSTATIC VALVE" in CHAPTER 5.
1	Drive sprocket cover 1	1	
2	Shift arm	1	
3	Drive sprocket cover 2	1	
4	Nut/Lock washer	1/1	
5	Drive sprocket/Drive chain	1/1	
6	Exhaust pipe/Muffler	1/1	
7	Exhaust pipe gasket	2	
8	Clutch cable	1	
9	Spark plug caps	2	
			For installation, reverse the removal procedure.