



FIG. 22 REAR ARM

REF. NO.	PART NO.	DESCRIPTION	5PS1	5PS2				REMARKS
1	5PS-22110-00	REAR ARM COMP.	1	1				
2	5PS-22184-00	BUSH	1	1				
3	93315-42523	BEARING	1	1				
4	93315-42536	BEARING	1	1				
5	5EB-22127-00	SHIM	1	1				
6	5EB-22123-00	BUSH 1	1	1				
7	3FV-22128-00	COVER, THRUST 1	1	1				
8	93109-33049	OIL SEAL	1	1				
9	5PS-22141-00	SHAFT, PIVOT	1	1				
10	90185-18167	NUT, SELF-LOCKING	1	1				
11	90201-186M4	WASHER, PLATE	1	1				
12	5PS-22125-00	BOLT	1	1				
13	93317-21746	BEARING	2	2				
14	93109-17071	OIL SEAL	2	2				
15	90387-126Y1	COLLAR	1	1				
16	5PS-2217A-00	ARM, RELAY	1	1				
17	5PS-2217M-00	ARM 1	2	2				
18	93317-21746	BEARING	2	2				
19	93317-31771	BEARING	2	2				
20	93109-17071	OIL SEAL	6	6				
21	90387-126Y1	COLLAR	1	1				
22	90101-12749	BOLT	2	2				
23	90185-12119	NUT, SELF-LOCKING	2	2				
24	92907-12600	WASHER	2	2				
25	90105-10323	BOLT, FLANGE	1	1				
26	95607-10200	NUT, SELF-LOCKING	1	1				
27	90387-1012B	COLLAR	1	1				