


3VD935I-5010


Ref No	Part No	Description
01	3VD-11101-20-00	Cylinder Head Assy
02	3LD-11133-10-00	• . Guide, Intake Valve
03	3LD-11134-10-00	• . Guide, Exhaust Valve
04	93440-10109-00	• . Circlip
05	99510-08016-00	• . Pin, Dowel
06	90340-18101-00	• . Plug, Straight Screw
07	90105-06153-00	• . Bolt, Washer Based
08	90116-08548-00	• . Bolt, Stud
09	90338-10150-00	• . Plug
10	94701-00241-00	Plug, Spark
10	94701-00242-00	Plug, Spark (nd X24epr-u9)
11	90201-103M4-00	Washer, Plate
12	90179-10414-00	Nut
13	91317-06150-00	Bolt
14	95024-08012-00	Bolt, Flange
15	90430-08119-00	Gasket
16	4NX-11181-00-00	Gasket, Cylinder Head 1
17	4NX-Y1119-10-00	Cover Assy, Cylinder Head
18	3LD-11193-01-00	• . Gasket, Head Cover 1
19	3LD-11160-02-00	• . Breather Assy
20	98507-04006-00	• . Screw, Pan Head
21	92907-04600-00	• . Washer
22	90109-064F0-00	Bolt
23	90109-062G1-00	Bolt
24	90109-062G2-00	Bolt
25	90209-11262-00	Washer
26	2GH-1111G-00-00	Rubber, Mount 1

Ref No	Part No	Description
01	4UN-11310-00-00	Cylinder
02	93210-90785-00	O-ring
03	3VD-11351-00-00	Gasket, Cylinder
04	99530-14016-00	Pin, Dowel
05	90153-06029-00	Screw, Hexagon
06	90430-06014-00	Gasket




4NX1010-5020

Ref No	Part No	Description
01	4NX-11400-00-00	Crankshaft Assy
02	3LD-11416-00-00	Plane Bearing, Crankshaft 1
02	3LD-11416-10-00	Plane Bearing, Crankshaft 1
02	3LD-11416-20-00	Plane Bearing, Crankshaft 1
02	3LD-11416-30-00	Plane Bearing, Crankshaft 1
02	3LD-11416-40-00	Plane Bearing, Crankshaft 1
02	3LD-11416-50-00	Plane Bearing, Crankshaft 1
02	3LD-11416-60-00	Plane Bearing, Crankshaft 1
03	4NX-11631-00-00	Piston (std)
03	4NX-11636-00-00	Piston (0.50mm O/s)
03	4NX-11638-00-00	Piston (1.00mm O/s)
04	3VD-11610-00-00	Piston Ring Set
04	3VD-11610-20-00	Piston Ring Set
04	3VD-11610-40-00	Piston Ring Set
05	3LD-11633-00-00	Pin, Piston
06	93450-22027-00	Circlip
07	3VD-11650-00-00	Connecting Rod Assy
08	3LD-11654-00-00	• . Bolt, Connecting Rod
09	90179-09379-00	• . Nut
10	3LD-11656-10-00	Plane Bearing, Connecting Rod
10	3LD-11656-20-00	Plane Bearing, Connecting Rod
10	3LD-11656-30-00	Plane Bearing, Connecting Rod
11	4NX-11500-00-00	Balancer Assy
12	4NX-11510-00-00	Balancer Assy, 2
13	3LD-11583-00-00	Shaft, Balancer 1
14	3LD-11584-00-00	Shaft, Balancer 2
15	93210-30660-00	O-ring
16	90280-05029-00	Key, Woodruff
17	90105-12584-00	Bolt, Washer Based
18	90201-121H0-00	Washer, Plate




4NX1010-5030




Ref No	Part No	Description
01	3LD-12111-01-00	Valve, Intake (3ld.)
02	3LD-12112-01-00	Valve, Intake 2 (3ld.)
03	3LD-12121-00-00	• . Valve, Exhaust (3ld)
04	1WG-12116-00-00	Seat, Valve Spring
05	3LD-12113-00-00	Spring, Valve Inner
06	3LD-12117-00-00	Retainer, Valve Spring
07	3LD-12118-00-00	Cotter, Valve
08	51Y-12119-00-00	Seal, Valve Stem
09	1WG-12153-11-00	Lifter, Valve
09	1WG-12153-21-00	Lifter, Valve
09	1WG-12153-31-00	Lifter, Valve
09	1WG-12153-09-00	Lifter, Valve
10	3LD-12168-00-00	Pad, Adjusting (1.20)
10	3LD-12168-M1-00	Pad, Adjusting (1.65)
10	3LD-12168-R1-00	Pad, Adjusting (1.70)
10	3LD-12168-U1-00	Pad, Adjusting (1.75)
10	3LD-12168-W1-00	Pad, Adjusting (1.80)
10	3LD-12168-Y1-00	Pad, Adjusting (1.85)
10	3LD-12169-11-00	Pad, Adjusting (1.90)
10	3LD-12169-31-00	Pad, Adjusting (1.95)
10	3LD-12169-50-00	Pad, Adjusting (2.00)
10	3LD-12169-70-00	Pad, Adjusting (2.05)
10	3LD-12169-90-00	Pad, Adjusting (2.10)
10	3LD-12168-20-00	Pad, Adjusting (1.25)
10	3LD-12169-E0-00	Pad, Adjusting (2.15)
10	3LD-12169-G0-00	Pad, Adjusting (2.20)
10	3LD-12169-J0-00	Pad, Adjusting (2.25)
10	3LD-12169-L0-00	Pad, Adjusting (2.30)
10	3LD-12169-N0-00	Pad, Adjusting (2.35)
10	3LD-12169-T0-00	Pad, Adjusting (2.40)
10	3LD-12168-40-00	Pad, Adjusting (1.30)
10	3LD-12168-60-00	Pad, Adjusting (1.35)
10	3LD-12168-80-00	Pad, Adjusting (1.40)
10	3LD-12168-A0-00	Pad, Adjusting (1.45)
10	3LD-12168-F0-00	Pad, Adjusting (1.50)
10	3LD-12168-H1-00	Pad, Adjusting (1.55)
10	3LD-12168-K1-00	Pad, Adjusting (1.60)

Ref No	Part No	Description
01	4NX-12171-00-00	Camshaft 1
02	4NX-12181-00-00	Camshaft 2
03	3LD-12176-00-00	Sprocket, Cam Chain
04	90105-07342-00	Bolt, Washer Based
05	94591-40138-00	Chain (82rh2015-138l)
06	3LD-12241-00-00	Guide, Stopper 2
07	3LD-12210-00-00	Tensioner Assy, Cam Chain
08	3VD-12213-00-00	Gasket, Tensioner Case
09	91314-06025-00	Bolt
10	3LD-12251-00-00	Damper, Chain 1
11	3LD-12252-00-00	Damper, Chain 2
12	3LD-12247-00-00	Shaft, Tensioner




3VD9351- 5050




Ref No	Part No	Description
01	4UN-Y1242-00-00	Water Pump Assy
02	3LD-12439-00-00	• . O-ring
03	95024-06020-00	• . Bolt, Flange
04	99009-12400-00	• . Circlip
05	95024-06012-00	• . Bolt, Flange
06	90430-06014-00	• . Gasket
07	93210-33133-00	• . O-ring
08	3VD-12459-00-00	Gear, Impeller Shaft
09	90201-127E1-00	Washer, Plate
10	95024-06030-00	Bolt, Flange
11	95024-06045-00	Bolt, Flange
12	95024-06060-00	Bolt, Flange
13	3LD-12481-00-00	Pipe 1
14	93210-21190-00	O-ring
15	93210-357A2-00	O-ring
16	4UN-12469-00-00	Joint 1
17	95027-06016-00	Bolt, Flange




4TX1351-6060




Ref No	Part No	Description
01	4TX-12461-40-00	Radiator Assy
02	4TX-12405-00-00	Blower Assy
03	1UF-12611-00-00	• . Fan
04	26H-12630-00-00	• . Motor Assy
05	98507-05008-00	• . Screw, Pan Head
06	92990-05600-00	• . Washer, Plate
07	4FL-12462-00-00	Cap, Radiator
08	1AA-12561-00-00	Plug, drain Cock
09	1AA-12435-00-00	Gasket
10	1KT-12437-00-00	Stopper
11	97007-05012-00	Bolt
12	92907-05600-00	Washer, Plate
13	3VD-12465-00-00	Damper, Radiator
14	4TX-12578-00-00	Hose 3
15	90450-38040-00	Hose Clamp Assy
16	1UF-12467-00-00	Cover, Radiator
17	1UF-12435-00-00	Gasket
18	90183-05024-00	Nut, Spring
19	4TX-12465-00-00	Damper, Radiator
20	98507-05010-00	Screw, Pan Head
21	92907-05600-00	Washer, Plate
22	90480-15363-00	Grommet
23	90387-0614M-00	Collar
24	90387-0714B-00	Collar
25	95807-06025-00	Bolt, Flange
26	90201-06071-00	Washer, Plate
27	4NX-12482-00-00	Pipe 2
28	93210-18417-00	O-ring
29	91317-06016-00	Bolt
30	90467-11090-00	Clip
31	4TX-12576-40-00	Hose 1
32	90450-32051-00	Hose Clamp Assy
33	1AE-12410-00-00	Thermostat Assy
34	4TX-12417-40-00	Housing, Thermostat
35	4NX-12413-00-00	Cover, Thermostat
36	93210-49046-00	O-ring
37	95027-06020-00	Bolt, Flange
38	95027-06025-00	Bolt, Flange
39	4TX-1244E-00-00	Bracket 1
40	95027-06014-00	Bolt, Flange
41	4NX-12579-00-00	Hose 4
42	98507-04008-00	Screw, Pan Head
43	92907-04600-00	Washer



Ref No	Part No	Description
F 01	3LD-13300-00-00	Oil Pump Assy
- 02	99530-08012-00	Pin, Dowel
03	3LD-13329-00-00	Gasket, Pump Cover
04	98507-06045-00	Screw, Pan Head
- 05	90430-14131-00	Gasket
06	90387-120W5-00	Collar
07	4NX-13303-00-00	Oil Pump Assy, 2
08	3LD-13371-00-00	• . Plate
09	3LD-13339-00-00	Gasket, Pump Cover
10	98507-06035-00	Screw, Pan Head
11	3VD-13325-00-00	Gear, Pump Driven
12	99009-11400-00	Circlip
13	3VD-13412-00-00	Housing, Strainer
14	95027-06025-00	Bolt, Flange
15	95027-06020-00	Bolt, Flange
16	3VD-13415-00-00	Seal, Oil Strainer
17	3VD-13411-00-00	Strainer, Oil
18	98504-06010-00	Screw, Pan Head
19	4X7-13440-01-00	Element Assy, Oil Cleaner
20	3VD-13447-00-00	Cover, Oil Element
21	93210-64297-00	O-ring
22	95024-06020-00	Bolt, Flange
23	95024-06030-00	Bolt, Flange
24	95024-06040-00	Bolt, Flange
25	3LD-13161-00-00	Pipe, Delivery 1
26	90401-10106-00	Bolt, Union
27	90430-10188-00	Gasket
28	3VD-13417-10-00	Cover, Strainer
29	3LD-13113-00-00	Seat, Check Ball
30	93505-08030-00	Ball
31	90501-104F9-00	Spring, Compression
32	90387-106W6-00	Collar
33	93210-12790-00	O-ring
34	11H-13490-00-00	Relief Valve Assy
35	93210-10096-00	O-ring
36	3LD-13151-00-00	Stay
37	90105-06553-00	Bolt, Washer Based
38	99530-08016-00	Pin, Dowel
39	4H7-15138-00-00	Nozzle 1
40	3VD-13414-00-00	Gasket, Strainer Cover
41	90105-06456-00	Bolt, Washer Based
42	95024-06025-00	Bolt, Flange
43	95024-10040-00	Bolt, Flange
44	90430-10188-00	Gasket
45	95027-06035-00	Bolt, Flange
46	90340-14132-00	Plug, Straight Screw
47	214-11198-01-00	Gasket
48	4UN-13464-01-00	Hose, Oil 1
49	93210-13657-00	O-ring
50	91314-06020-00	Bolt
51	4TX-13465-00-00	Hose, Oil 2
52	90460-27270-00	Clamp, Hose
53	3VD-13416-00-00	Pipe, Oil 1
54	93210-13657-00	O-ring




Ref No	Part No	Description
55	90110-06093-00	Bolt, Hexagon Socket Head
F 56	4NX-13418-00-00	Pipe, Oil 2
- 57	93210-13657-00	O-ring
58	91314-06020-00	Bolt
59	3VD-13317-00-00	Plate, Baffle
- 60	90105-06553-00	Bolt, Washer Based
61	4TX-13416-00-00	Pipe, Oil 1
62	93210-16629-00	O-ring
63	91314-06020-00	Bolt
64	4TX-13132-00-00	Joint
65	93210-26741-00	O-ring
66	91314-06025-00	Bolt
67	3F9-15362-00-00	Plug, Oil Level
68	93210-27370-00	O-ring
69	4TX-13467-00-00	Hose
70	90450-32051-00	Hose Clamp Assy
71	4TX-13266-00-00	Connector, Oil
72	90450-38040-00	Hose Clamp Assy
73	95027-06016-00	Bolt, Flange
74	90387-085N0-00	Collar
75	93210-10096-00	O-ring
76	90387-106W6-00	Collar
77	93210-12790-00	O-ring
78	90387-06761-00	Collar
79	93210-07135-00	O-ring
80	90387-130W6-00	Collar
81	93210-15566-00	O-ring



4TX4351-9090


Ref No	Part No	Description
01	3LD-13586-01-00	Joint, Carburetor 1
02	3LD-13597-01-00	Joint, Carburetor 3
03	90445-090E5-00	Hose
04	90467-08014-00	Clip
05	90467-08075-00	Clip
06	90338-05194-00	Plug
07	93210-44545-00	O-ring
08	91317-06020-00	Bolt
09	90465-20035-00	Clamp
10	90450-57034-00	Hose Clamp Assy
11	4TX-14411-40-00	Case, Air Cleaner 1
12	3VD-14421-00-00	Case, Air Cleaner 2
13	4BR-14452-00-00	Seal
14	97707-50125-00	Screw, Tapping
15	1AE-14451-00-00	Element, Air Cleaner
16	3VD-14422-00-00	Cap, Cleaner Case 2
17	1AE-14452-00-00	Seal
18	98507-05016-00	Screw, Pan Head
19	92907-05600-00	Washer, Plate
20	4TX-14453-40-00	Joint, Air Cleaner 1
21	4TX-14425-40-00	Damper 1
22	4TX-14426-40-00	Damper 2
23	3VD-1442G-00-00	Damper 3
24	4N0-24181-00-00	Damper, Locating 1
25	90480-14604-00	Grommet
26	90387-07391-00	Collar
27	90450-75083-00	Hose Clamp Assy
28	97007-06025-00	Bolt
29	90201-06063-00	Washer, Plate
30	4TX-11166-01-00	Pipe, Breather 1
31	90467-22080-00	Clip
32	90467-24113-00	Clip




Ref No	Part No	Description
01	4TX-14900-40-00	Carburetor Assy
02	4TX-14901-40-00	• Carburetor Assy 1
03	4TX-14902-40-00	• Carburetor Assy 2
04	4SV-14968-00-00	• Cap
05	4TX-14275-00-00	• Spring
06	4TX-1490J-40-00	• Needle Set
06	4TX-1490J-50-00	• Needle Set
07	5DM-14105-00-00	• Pilot Screw Set
08	4SV-24411-00-00	• Diaphragm
09	4SV-14112-00-00	• Valve, Throttle 1
10	4TX-14479-00-00	• Funnel
11	4TX-14261-00-00	• Holder
12	3G2-1423A-80-00	• Jet, Main (147.5)
13	1HX-1423A-68-00	• Jet, Main (87.5)
14	4KM-14142-17-00	• Jet, Pilot (17.5)
15	4KM-14107-15-00	• Needle Valve Set
16	620-14186-00-00	• Pin, Float
17	4SV-14985-00-00	• Float
18	1FN-14565-00-00	• Screw
19	4SV-1410A-00-00	• Starter Set
20	98507-04018-00	• Screw, Pan Head
21	98507-04008-00	• Screw, Pan Head
22	98507-05010-00	• Screw, Pan Head
23	1HX-14231-24-00	• Jet, Main ((1200
24	4KP-14191-00-00	• Plug, Drain
25	98507-04014-00	• Screw, Pan Head
26	92907-04100-00	• Washer, Spring
27	4XY-14589-00-00	• Spring
28	5AP-14940-00-00	• Diaphragm Assy
29	90461-06087-00	• Clamp
30	4TX-14264-00-00	• Collar
31	4KM-14216-00-00	• Screw
32	98507-05012-00	• Screw, Pan Head
33	4WM-14565-00-00	• Screw
34	4TX-14348-00-00	• Pipe 1
35	4SV-14987-00-00	• Hose
36	4TX-14148-10-00	• Pipe
37	36Y-14147-00-00	• O-ring
38	4TX-14419-00-00	• Pipe
39	4SV-14935-00-00	• Spring
40	4TX-14148-00-00	• Pipe
41	4TX-14349-00-00	• Pipe
42	3JE-14197-00-00	• Pipe
43	3JD-14197-00-00	• Pipe
44	4TX-14103-40-00	• Throttle Screw Set
45	4NK-14327-00-00	• Screw
46	4XV-24453-00-00	• Screw
47	3EN-1490K-00-00	• Stop Screw Set
48	5DM-14919-00-00	• Clip
49	4TX-1243A-40-00	• Hose 1
50	4TX-1243F-40-00	• Hose,3
51	90467-09037-00	• Clip
52	4TX-85885-00-00	• Throttle Sensor Assy
53	4HM-14239-00-00	• Seal

CARBURETOR

Ref No	Part No	Description
54	4TX-14148-40-00	Pipe
55	90467-15012-00	Clip
56	90464-12238-00	Clamp



4TX4351-9100



Ref No	Part No	Description
01	4TX-14602-01-00	Exhaust Pipe Comp.
02	92990-06600-00	• . Washer, Plate
03	90101-06576-00	• . Bolt
04	3VD-14613-00-00	Gasket, Exhaust Pipe
05	90179-08345-00	Nut
06	4TX-14710-40-00	Muffler Assy 1
07	3VD-14755-00-00	• . Gasket, Silencer
08	95027-08025-00	• . Bolt, Flange
09	90201-08326-00	Washer, Plate
10	91317-08110-00	Bolt
11	90105-10271-00	Bolt, Washer Based
12	95707-10500-00	Nut, Flange




4TX1351-6110

TDM850(294TX-332G1)


12

CRANKCASE



4TX1351-6120


Ref No	Part No	Description
01	3VD-15100-22-00	Crankcase Assy
02	2H7-15138-00-00	• . Nozzle 1
03	4G0-15138-00-00	• . Nozzle 1
04	99530-10114-00	• . Pin, Dowel
05	3VD-15316-00-00	• . Damper, Engine Mount 1
06	3VD-15317-00-00	• . Spacer, Engine Mount
07	93210-12095-00	• . O-ring
08	90338-11257-00	Plug
09	3VD-15199-00-00	Bracket
10	91314-08016-00	Bolt
11	99530-14016-00	Pin, Dowel
12	3LD-11361-00-00	Bolt, Cylinder Holding 1
13	90105-10560-00	Bolt, Washer Based
14	90201-11597-00	Washer, Plate
15	95814-06040-00	Bolt, Flange
16	90201-066F0-00	Washer, Plate
17	95817-06055-00	Bolt, Flange
18	95817-06020-00	Bolt, Flange
19	95817-06030-00	Bolt, Flange
20	95814-08050-00	Bolt, Flange
21	90201-08087-00	Washer, Plate
22	95814-08060-00	Bolt, Flange
23	90201-08087-00	Washer, Plate
24	95817-06070-00	Bolt, Flange
25	95817-08065-00	Bolt, Flange
26	95814-08050-00	Bolt, Flange
27	95817-08070-00	Bolt, Flange
28	95817-08075-00	Bolt, Flange
29	95817-06025-00	Bolt, Flange
30	95814-06040-00	Bolt, Flange
31	90201-066F0-00	Washer, Plate
32	90465-08341-00	Clamp
33	3LD-15191-00-00	Plate
34	90149-06285-00	Screw
35	3LD-15118-00-00	Holder
36	99530-08016-00	Pin, Dowel
37	95817-06045-00	Bolt, Flange
38	95817-06070-00	Bolt, Flange
39	3VD-15416-10-00	Cover, Oil Pump
40	3VD-15456-00-00	Gasket, Oil Pump Cover 1
41	95024-06020-00	Bolt, Flange
42	99530-08012-00	Pin, Dowel



Ref No	Part No	Description
01	3VD-15411-11-00	Cover, Crankcase 1
02	93317-21236-00	Bearing
03	93109-12075-00	Oil Seal
04	3VD-15451-00-00	Gasket, Crankcase Cover 1
05	99530-08012-00	Pin, Dowel
06	95024-06025-00	Bolt, Flange
07	90105-06456-00	Bolt, Washer Based
08	90465-08127-00	Clamp
09	3LD-15418-00-00	Cover, Chain Case
10	95027-06025-00	Bolt, Flange
11	90465-08122-00	Clamp
12	3VD-15420-01-00	Crankcase Cover Assy 2
13	3VD-15326-00-00	• . Damper, Engine Mount 2
14	3VD-15335-00-00	• . Damper 3
15	95024-06030-00	Bolt, Flange
16	95024-06055-00	Bolt, Flange
17	4UN-15430-00-00	Crankcase Cover Assy 3
18	3VD-15417-01-00	• . Cover, Cap
19	3LD-15449-00-00	• . Ring, Rubber
20	1JK-15486-00-00	• . Grommet
21	90209-05279-00	• . Washer
22	98507-05010-00	• . Screw, Pan Head
23	4NX-15462-01-00	Gasket, Crankcase Cover 3
24	95024-06025-00	Bolt, Flange
25	90465-15384-00	Clamp
26	99530-08012-00	Pin, Dowel
27	4UN-15425-01-00	Cover, Generator 2
28	95027-06035-00	Bolt, Flange
29	4UN-15426-00-00	Cover, Oil Pump 2
30	99530-08012-00	Pin, Dowel
31	3VD-15463-00-00	Gasket, Carburetor Cover 2
32	90462-20223-00	Clamp
33	95024-06035-00	Bolt, Flange
34	95024-06045-00	Bolt, Flange
35	95024-06055-00	Bolt, Flange
36	90105-06131-00	Bolt, Washer Based
37	95024-06110-00	Bolt, Flange
38	95817-06090-00	Bolt, Flange
39	99530-10114-00	Pin, Dowel
40	4NX-15461-00-00	Gasket, Crankcase Cover 2
41	90340-14151-00	Plug, Straight Screw
42	93210-14369-00	O-ring
43	90340-32116-00	Plug, Straight Screw
44	93210-32172-00	O-ring
45	90465-20342-00	Clamp




4TX4351-9130




3LDI351-9I40

Ref No	Part No	Description
01	4NX-15515-00-00	Gear 3
02	3LD-15517-00-00	Gear, Idler 2
03	26H-15521-00-00	Shaft 1
04	3LD-15512-00-00	Gear, Idler 1
05	3LD-15590-02-00	Starter One-way Assy
06	91317-06018-00	Bolt
07	90201-301P3-00	Washer, Plate
08	3LD-81800-00-00	Starting Motor Assy
09	3AJ-81801-00-00	• . Brush Set
10	3AJ-81809-00-00	• . Washer Kit
11	3AJ-81830-00-00	• . Front Bracket Assy
12	3AJ-81826-00-00	• . Bolt
13	11H-81844-00-00	• . Gasket
14	1FK-81847-00-00	• . O-ring
15	3LD-81815-00-00	• . Cord, Starter Motor
16	4G0-81871-00-00	•• .. Cap
17	95817-06050-00	Bolt, Flange




Ref No	Part No	Description
01	4TX-16150-01-00	Primary Driven Gear Comp.
02	3LD-1637A-01-00	Rod Push Assy
03	93340-21505-00	Bearing
04	90201-150U6-00	Washer, Plate
05	4H7-16154-00-00	Plate, Thrust 1
06	4TX-16371-00-00	Boss, Clutch
07	4H7-16321-02-00	Plate, Friction
08	4TX-16321-00-00	Plate, Friction
09	3LD-16351-00-00	Plate, Pressure 1
10	90501-237L0-00	Spring, Compression
11	90159-06123-00	Screw, With Washer
12	3J2-16324-00-00	Plate, Clutch 1
13	90215-20231-00	Washer, Lock
14	90170-20237-00	Nut
15	4TX-16340-40-00	Push Lever Assy
16	90508-167A3-00	Spring, Torsion
17	3LD-16382-00-00	Axle, Push Lever
18	3LD-16398-00-00	Pinion, Releas
19	92907-08600-00	Washer, Plate
20	99001-07600-00	Circlip
21	93317-11020-00	Bearing
22	93102-12224-00	Oil Seal
23	90201-12163-00	Washer, Plate
24	93315-11206-00	Bearing
25	90201-10119-00	Washer, Plate
26	99009-10400-00	Circlip
27	3VD-16164-00-00	Plate, Thrust 2
28	3VD-16154-00-00	Plate, Thrust 1
29	4NX-16181-00-00	Spacer 1
30	93310-365B8-00	Bearing




4TX4351-9160

Ref No	Part No	Description
01	4TX-17411-40-00	Axle, Main
02	4TX-17151-40-00	Gear, 5th Pinion (28z)
03	90209-21332-00	Washer
04	93440-25084-00	Circlip
05	4TX-17131-40-00	Gear, 3rd Pinion ((20z0
06	2GH-17141-00-00	Gear, 4th Pinion ((23z0
07	4TX-17121-40-00	Gear, 2nd Pinion ((19z0
08	93306-30525-00	Bearing ((b63050
09	90387-253M6-00	Collar
10	90387-203M7-00	Collar
11	90201-200K3-00	Washer, Plate
12	3LD-15163-10-00	Housing, Bearing 1
13	93306-20464-00	Bearing
14	90149-06286-00	Screw
15	4TX-17402-40-00	Drive Axle Assy
16	90209-29329-00	Washer
17	90209-28330-00	Washer
18	90387-2802W-00	Collar
19	4TX-17231-40-00	Gear, 3rd Wheel (30z)
20	4NX-17241-00-00	Gear, 4th Wheel (27z)
21	90209-28331-00	Washer
22	93440-31172-00	Circlip
23	4TX-17251-40-00	Gear, 5th Wheel (27z)
24	4TX-17211-40-00	Gear, 1st Wheel (37z)
25	93102-35459-00	Oil Seal
26	9384E-16191-00	Sprocket, Drive (16z)
27	90215-21290-00	Washer, Lock
28	90179-18667-00	Nut
29	90201-20278-00	Washer, Plate
30	93306-20455-00	Bearing
31	93440-45144-00	Circlip
32	4NX-17471-00-00	Plate, Cover
33	95827-06012-00	Bolt, Flange
34	3LD-15414-00-00	Cover, Air Cleaner
35	93210-33133-00	O-ring




Ref No	Part No	Description
01	4TX-18540-40-00	Shift Cam Assy
02	90149-05321-00	• . Screw
03	4UN-18542-00-00	• . Point, Neutral
04	90501-06022-00	• . Spring, Compression
05	4UN-18566-00-00	• . Plate, Side 2
06	90105-06597-00	Bolt, Washer Based
07	90105-06397-00	Bolt, Washer Based
08	3VD-18511-00-00	Fork, Shift 1
09	3VD-18512-00-00	Fork, Shift 2
10	3VD-18513-00-00	Fork, Shift 3
11	4NX-18531-00-00	Bar, Shift Fork Guide 1
12	4NX-18535-00-00	Bar, Shift Fork Guide 2
13	3LD-18536-00-00	Stopper, Shift Bar
14	90508-297A4-00	Spring, Torsion
15	4SV-18140-00-00	Stopper Lever Assy
16	90105-06557-00	Bolt, Washer Based
17	4NX-18175-00-00	Spacer



Ref No	Part No	Description
01	3LD-18101-02-00	Shift Shaft Assy
02	90508-32682-00	• . Spring, Torsion
03	90201-191J4-00	• . Washer, Plate
04	99009-19400-00	• . Circlip
05	90201-12575-00	Washer, Plate
06	99001-10600-00	Circlip
07	3LD-18130-00-00	Shift Shaft Assy
08	2H9-18154-00-00	• . Cover, Dust
09	95827-06020-00	Bolt, Flange
10	3VD-18115-00-00	Rod, Shift
11	90170-06228-00	Nut (verkehtheit Schraube)
12	95304-06700-00	Nut
13	3VD-18110-10-00	Shift Pedal Assy
14	2H9-18154-00-00	• . Cover, Dust
15	132-18113-01-00	• . Cover, Shift Pedal
16	2YK-27434-01-00	Bolt
17	90206-12074-00	Washer, Wave
18	90201-08326-00	Washer, Plate
19	4G0-18127-00-00	Stopper, Screw
20	93101-12004-00	Oil Seal




3VD1351-1180



Ref No	Part No	Description
01	4TX-21110-40-35	Frame Comp.
02	3VD-21411-10-35	Bracket, Engine 1
03	4TX-21419-00-35	Bracket, Engine 2
04	90109-083G1-00	Bolt
05	91314-10045-00	Bolt
06	91314-10060-00	Bolt
07	91314-10025-00	Bolt
08	90201-10430-00	Washer, Plate
09	90110-10229-00	Bolt, Hexagon Socket Head
10	90179-10377-00	Nut
11	3VD-21489-00-00	Bracket, Engine Lower
12	90105-08752-00	Bolt, Washer Based
13	90105-10328-00	Bolt, Washer Based
14	4TX-2135F-01-00	Cover
15	3LD-2143A-00-00	Cap
16	11H-21747-00-00	Damper
17	3VD-2143A-00-00	Cap
18	3VD-21164-00-00	Holder, Cable
19	95807-06010-00	Bolt, Flange
20	3YL-12232-00-00	Damper
21	4TX-21161-00-00	Holder, Cable
22	90105-06446-00	Bolt, Washer Based
23	4TX-2148U-40-00	Bracket 1
24	95024-06010-00	Bolt, Flange
25	3YX-2171L-00-00	Mole, Side Cover 1
26	4KB-21268-00-00	Seal




4TX4351-9190



4TX1351-6200

Ref No	Part No	Description
01	3VD-Y2151-10-4B	Front Fender Comp.
01	3VD-Y2151-10-P9	Front Fender Comp.
01	3VD-Y2151-10-PA	Front Fender Comp.
02	3GM-21512-00-00	• . Bracket, Fender
03	90267-32071-00	• . Rivet, Blind
04	90387-065T2-00	• . Collar
05	90338-12192-00	• . Plug
06	90105-06477-00	Bolt, Washer Based
07	3FY-21575-01-00	• . Seal 1
08	3VD-Y2161-01-00	Rear Fender C0mp.
09	90480-10258-00	• . Grommet
10	3VD-21366-00-00	• . Hook, Tool Band
11	90267-40073-00	• . Rivet, Blind
12	3HE-85132-01-00	• . Bracket, Reflector 1
13	90267-40035-00	• . Rivet, Blind
14	90201-04018-00	• . Washer, Plate
15	95027-06010-00	Bolt, Flange
16	95027-06020-00	Bolt, Flange
17	90387-064J1-00	Collar
18	90183-06023-00	Nut, Spring
19	2MG-21639-00-00	Damper 2
20	4TX-2471K-00-P4	Cover, Tail 1
20	4TX-2471K-00-P2	Cover, Tail 1
20	4TX-2471K-00-P3	Cover, Tail 1
21	4TX-21781-70-00	Emblem 1
21	4TX-21781-80-00	Emblem 1
21	4TX-21781-90-00	Emblem 1
22	98907-05010-00	Screw, Bind
23	90183-05024-00	Nut, Spring
24	97707-50012-00	Screw, Tapping
25	4KB-21268-00-00	Seal
26	4TX-2472K-00-P4	Cover, Tail 2
26	4TX-2472K-00-P2	Cover, Tail 2
26	4TX-2472K-00-P3	Cover, Tail 2
27	4TX-21781-70-00	Emblem 1
27	4TX-21781-80-00	Emblem 1
27	4TX-21781-90-00	Emblem 1
28	92017-06012-00	Bolt, Button Head
29	4TX-21651-00-P4	Cover, Rear Fender
29	4TX-21651-00-P2	Cover, Rear Fender
29	4TX-21651-00-P3	Cover, Rear Fender
30	99236-00080-00	Emblem, Yamaha
30	99234-00080-00	Emblem, Yamaha
31	4TX-2161A-00-00	Bracket 3
32	97707-50012-00	Screw, Tapping
33	90480-12550-00	Grommet
34	3VD-21645-00-P9	Stay, Rear
34	3VD-21645-00-P6	Stay, Rear
34	3VD-21645-00-P7	Stay, Rear
35	95827-08040-00	Bolt, Flange
36	4TX-2117E-00-00	Bracket, Taillight
37	46X-21269-00-00	Seal
38	90109-085E2-00	Bolt
39	4TX-28100-00-00	Tool Kit


Ref No	Part No	Description
40	116-82131-00-00	Band, Battery
41	133-82131-00-00	Band, Battery




4TX1351-6200

Ref No	Part No	Description
--------	---------	-------------

01	4TX-2177G-00-00	Box, Battery
02	3Y6-21747-00-00	Damper
03	4TX-21732-00-00	Seal 1
04	4TX-21735-00-00	Seal 2
05	4TX-2173M-00-00	Seal 3
06	90159-06093-00	Screw, With Washer
07	90183-06053-00	Nut, Spring
08	51Y-21639-00-00	Damper 2
09	50M-21638-00-00	Damper 1
10	91317-06025-00	Bolt
11	90201-06071-00	Washer, Plate
12	90560-07007-00	Spacer
13	90480-16404-00	Grommet
14	91317-06025-00	Bolt
15	90201-06071-00	Washer, Plate
16	90387-07674-00	Collar
17	90480-16233-00	Grommet
18	90480-13369-00	Grommet
19	3VD-21871-00-00	Tank, Recovery
20	90119-06056-00	Bolt, With Washer
21	1AA-21815-00-00	Cap
22	1AA-21874-00-00	•. Gasket
23	90445-086J6-00	Hose
24	90467-08075-00	Clip
25	3VD-21816-00-00	Pipe 1
26	90464-10190-00	Clamp
27	4TX-21711-00-00	Cover, Side 1
28	4TX-21721-00-00	Cover, Side 2
29	90480-01603-00	Grommet
30	90159-06059-00	Screw, With Washer
31	4TX-21652-01-00	Protector
32	51Y-21639-00-00	Damper 2




4TX1351-6210



Ref No	Part No	Description
01	4TX-22110-00-00	Rear Arm Comp.
02	33M-22184-00-00	Bush
03	93320-32403-00	Bearing
04	4X7-22129-00-00	Cover, Thrust 2
05	90201-161J3-00	Washer, Plate
06	46X-22141-00-00	Shaft, Pivot
07	90185-14112-00	Nut, Self-locking
08	3VD-22311-00-00	Case, Chain
09	90119-06044-00	Bolt, With Washer
10	3VD-22151-00-00	Seal, Guard
11	90387-06681-00	Collar
12	90119-06108-00	Bolt, With Washer
13	3VD-25875-01-00	Holder, Brake Hose 1
14	90387-064J1-00	Collar
15	97007-06025-00	Bolt
16	92907-06600-00	Washer, Plate
17	3VD-W2165-00-00	Cover, Rear Fender
18	3VD-2164F-00-00	• . Stay 1
19	90267-40105-00	• . Rivet, Blind




4TX1351-6220



Ref No	Part No	Description
01	4TX-22210-00-00	Shock Absorber Assy, Rear
02	3VD-22216-00-00	• . Bush, Rear Shock Absorber
03	90384-18190-00	• . Bush, Bimetal Formed
04	90387-127X0-00	• . Collar
05	93109-18020-00	• . Oil Seal
06	90109-125F1-00	Bolt
07	95607-12100-00	Nut, U
08	90101-10659-00	Bolt
09	90201-124G9-00	Washer, Plate
10	95617-10100-00	Nut, U
11	3VD-22464-00-00	Knob, Control
12	10V-83365-00-00	Cap




4TX1351-6230



Ref No	Part No	Description
01	93399-99931-00	Bearing
02	93399-99932-00	Bearing
03	1W1-23416-00-00	Cover, Ball Race 2
04	90179-25033-00	Nut
05	90202-26142-00	Washer, Plate
06	26H-23418-01-00	Washer, Special
07	90202-24190-00	Washer, Plate
08	3FV-23462-00-00	Seal, Steering
09	90176-22081-00	Nut, Crown
10	90201-220T0-00	Washer, Plate
11	4TX-23435-00-00	Crown, Handle
12	91314-08030-00	Bolt
13	4H7-23441-00-P0	Holder, Handle Upper
14	4TX-23389-00-00	Guide, Cable
15	4TX-2331E-00-00	Guide, Cable
16	90105-06556-00	Bolt, Washer Based
17	91314-08030-00	Bolt
18	90338-08163-00	Plug




4TX4351-9240




4TX1351-6250

Ref No	Part No	Description
01	4TX-23102-01-00	Front Fork Assy (l.h)
02	4TX-23126-01-00	• . Tube, Outer (left)
03	4TX-23110-00-00	• . Inner Tube Comp.1
04	4TX-23135-A0-00	•• .. Metal, Slide 2
05	4TX-23170-00-00	• . Cylinder Comp., Front Fork
06	4TX-23151-00-00	• . Spring, Rebound
07	4TX-23157-00-00	• . Ring, Piston
08	4TX-23173-00-00	• . Spindle, Taper
09	91317-10025-00	• . Bolt
10	90430-10171-00	• . Gasket
11	4TX-23125-A0-00	• . Metal, Slide 1
12	4TX-23115-00-00	• . Guide, Cover Upper
13	4TX-23145-00-00	• . Oil Seal
14	4TX-23156-00-00	• . Clip, Oil Seal
15	4TX-23144-00-00	• . Seal, Dust
16	4TX-2311H-00-00	• . Fork, Bolt
17	93210-34504-00	• . O-ring
18	4TX-2311G-00-00	• . Bolt, Springadjust
19	4TX-2319K-00-00	• . Plunger Kit
20	4TX-2331L-00-00	• . Seat, Spring Upper
21	93210-18N01-00	• . O-ring
22	4TX-23141-00-00	• . Spring, Front Fork
23	4TX-2331G-00-00	• . Cover
24	4TX-23103-01-00	Front Fork Assy (r.h)
25	4TX-23136-01-00	• . Tube, Outer (right)
26	4TX-23110-00-00	• . Inner Tube Comp.1
27	4TX-23135-A0-00	•• .. Metal, Slide 2
28	4TX-23170-00-00	• . Cylinder Comp., Front Fork
29	4TX-23151-00-00	• . Spring, Rebound
30	4TX-23157-00-00	• . Ring, Piston
31	4TX-23173-00-00	• . Spindle, Taper
32	91317-10025-00	• . Bolt
33	90430-10171-00	• . Gasket
34	4TX-23125-A0-00	• . Metal, Slide 1
35	4TX-23115-00-00	• . Guide, Cover Upper
36	4TX-23145-00-00	• . Oil Seal
37	4TX-23156-00-00	• . Clip, Oil Seal
38	4TX-23144-00-00	• . Seal, Dust
39	4TX-2311H-00-00	• . Fork, Bolt
40	93210-34504-00	• . O-ring
41	4TX-2311G-00-00	• . Bolt, Springadjust
42	4TX-2319K-00-00	• . Plunger Kit
43	4TX-2331L-00-00	• . Seat, Spring Upper
44	93210-18N01-00	• . O-ring
45	4TX-23141-00-00	• . Spring, Front Fork
46	4TX-2331G-00-00	• . Cover
47	91317-08040-00	• . Bolt
48	4TX-23340-00-00	Under Bracket Comp.
49	91317-10030-00	Bolt
50	4KM-23123-01-00	Cover, Lower 1




4TX4332-9260

Ref No	Part No	Description
01	4TX-Y2410-70-01	Fuel Tank Comp.
01	4TX-Y2410-70-03	Fuel Tank Comp.
01	4TX-Y2410-70-02	Fuel Tank Comp.
02	4TX-24240-70-00	• . Graphic Set
02	4TX-24240-80-00	• . Graphic Set
02	4TX-24240-90-00	• . Graphic Set
03	99226-00140-00	• . Emblem, Yamaha
03	99224-00140-00	• . Emblem, Yamaha
04	4TX-24191-00-00	Bracket, Fuel Tank 1
05	4TX-24192-00-00	Bracket, Fuel Tank 2
06	3VD-24181-00-00	Damper, Locating 1
07	47X-24183-00-00	Damper, Locating 3
08	47X-24186-00-00	Washer, Special
09	90387-06605-00	Collar
10	92017-06035-00	Bolt, Button Head
11	90109-086A0-00	Bolt
12	2GH-24184-00-00	Damper, Locating 4
13	3Y6-24183-00-00	Damper, Locating 3
14	12R-24186-00-00	Washer, Special
15	97007-08030-00	Bolt
16	4TX-2411K-00-00	Stopper
17	4KM-24500-10-00	Fuel Cock Assy 1
18	4X8-24512-00-00	• . Gasket
19	98507-03008-00	• . Screw, Pan Head
20	3AJ-24534-00-00	• . Seal, Cock
21	3AJ-24523-00-00	• . Valve
22	90149-06011-00	Screw
23	90202-05193-00	Washer, Plate
24	4TX-24311-40-00	Pipe, Fuel 1
25	4TX-24315-40-00	Pipe 5
26	90467-12053-00	Clip
27	4HM-24602-00-00	Cap Assy
28	90110-05112-00	Bolt, Hexagon Socket Head
29	91317-05010-00	Bolt
30	90445-106J2-00	Hose
31	90467-09006-00	Clip
32	30X-2139X-00-00	Damper
33	4TX-2452E-40-00	Stay
34	95607-06200-00	Nut, Self U-flange
35	3CV-24491-10-00	Bracket, Fuel Pump
36	90387-062L2-00	Collar
37	90480-13163-00	Grommet
38	95807-06016-00	Bolt, Flange
39	98507-05010-00	Screw, Pan Head
40	1FK-24560-00-00	Filter Assy
41	1FK-24566-00-00	Bracket, Filter
42	90464-15192-00	Clamp
43	4TX-13907-40-00	Fuel Pump Comp.
44	4TX-14294-40-00	Hose
45	90467-12053-00	Clip
46	90445-11153-00	Hose
47	4X7-2149Y-00-00	Filter Assy
48	90445-112E1-00	Hose
49	90467-11106-00	Clip



4TX4332-9260

Ref No	Part No	Description
50	90467-10041-00	Clip
51	90338-08174-00	Plug
52	90445-107H3-00	Hose
53	90467-09006-00	Clip




Ref No	Part No	Description
01	4TX-24730-01-00	Double Seat Assy
02	4TX-24731-00-00	. Cover, Seat
03	4TX-24776-01-00	. Lever, Seat
04	4TX-2478F-00-00	. Rod, Connecting
05	4TX-24728-00-00	. Bracket, Seat
06	4TX-24718-00-00	. Bracket, Seat
07	90179-06635-00	. Nut
08	4TX-21376-00-00	. Band, Tool
09	22W-24741-00-00	. Pad, Seat
10	509-24724-00-00	. Damper, Seat
11	4BH-24705-00-00	Seat Lock Assy
12	95707-05500-00	Nut, Flange
13	47X-24796-00-00	Cover
14	4TX-24748-00-00	Bracket, Seat




4TX1351-6270

Ref No	Part No	Description
01	3VD-25168-00-7B	Cast Wheel, Front
02	90560-17233-00	Spacer
03	93306-30319-00	Bearing
04	93102-28022-00	Oil Seal
06	93900-00030-00	Valve, Rim
07	29L-25398-00-00	Balancer, Wheel
07	29L-25398-10-00	Balancer, Wheel
07	29L-25398-20-00	Balancer, Wheel
08	3GM-25181-03-00	Axle, Wheel
09	90387-177R1-00	Collar




4TX4351-9280




4TX4351-9290

Ref No	Part No	Description
01	4HM-2581T-01-00	Disc Brake Assy
02	90109-083G4-00	Bolt
03	3HE-2580T-70-00	Caliper Assy (left)
04	3HE-W0057-50-00	• Piston Assy, Caliper
05	3HE-W0047-50-00	• .. Caliper Seal Kit
06	3GM-W0045-03-00	• Brake Pad Kit
07	3GM-25919-00-00	• Support, Pad
08	3HE-25924-00-00	• Pin, Pad
09	3GM-25925-00-00	• Clip
10	1J3-W0048-00-00	• Bleed Screw Kit
11	1KT-25836-00-00	• Cover, Dust
12	3HE-2580U-70-00	Caliper Assy (right)
13	3HE-W0057-50-00	• Piston Assy, Caliper
14	3HE-W0047-50-00	• .. Caliper Seal Kit
15	3GM-W0045-03-00	• Brake Pad Kit
16	3GM-25919-00-00	• Support, Pad
17	3HE-25924-00-00	• Pin, Pad
18	3GM-25925-00-00	• Clip
19	1J3-W0048-00-00	• Bleed Screw Kit
20	1KT-25836-00-00	• Cover, Dust
21	90105-10638-00	Bolt, Washer Based
22	4YR-23317-00-00	Holder, Cable



4TX1351-6300

Ref No	Part No	Description
01	3VD-25338-00-7B	Cast Wheel, Rear
02	93306-30320-00	Bearing
03	93306-20314-00	Bearing
04	93102-25044-00	Oil Seal
05	90387-173M5-00	Collar
06	4TX-25364-40-00	Damper
07	93306-20314-00	Bearing
09	93900-00030-00	Valve, Rim
10	29L-25398-00-00	Balancer, Wheel
10	29L-25398-10-00	Balancer, Wheel
10	29L-25398-20-00	Balancer, Wheel
11	1AE-25366-00-00	Clutch, Hub
12	93306-37207-00	Bearing
13	93105-42024-00	Oil Seal
14	4TX-25443-40-00	Sprocket, Driven
15	90116-10485-00	Bolt, Stud
16	95607-10200-00	Nut, Self-locking
17	90387-177K0-00	Collar
18	94581-45114-00	Chain (d.i.d. 525hv-114le)
19	3HE-25388-00-00	Puller, Chain 1
20	92907-08200-00	Washer
21	95307-08600-00	Nut
22	3HE-22174-00-00	End 1
23	3AJ-25381-01-00	Axle, Wheel
24	90201-170T3-00	Washer, Plate
25	90387-177Y5-00	Collar
26	90387-177Y4-00	Collar
27	95604-16200-00	Nut, U Flange
28	90201-160T2-00	Washer, Plate




Ref No	Part No	Description
01	4HM-2582W-00-00	Disc, Rear Brake 2
02	90109-083G4-00	Bolt
03	4TX-2580W-00-00	Caliper Assy, Rear 2
04	31A-W0057-00-00	. Piston Assy, Caliper
05	31A-W0047-00-00	• • Caliper Seal Kit
06	4SV-W0045-50-00	. Brake Pad Kit
07	29L-25919-00-00	. Support, Pad
08	3HE-25924-00-00	. Pin, Pad
09	3GM-25925-00-00	. Clip
10	1J3-W0048-00-00	. Bleed Screw Kit
11	42H-25836-00-00	. Cover, Dust
12	1FK-25827-00-00	. Shim, Caliper
13	1FK-25828-00-00	. Shim, Caliper
14	3VD-25819-00-00	Bracket, Caliper
15	90105-10638-00	Bolt, Washer Based
16	95827-10030-00	Bolt, Flange
17	90201-10437-00	Washer, Plate




3VD1351-1310

Ref No	Part No	Description
01	3VD-26111-20-00	Handlebar
02	1KG-26241-00-00	Grip (left)
03	3FH-26240-00-00	Grip Assy
04	51J-26246-01-00	End, Grip
05	4TX-26302-40-00	Throttle Cable Assy
06	3XW-26281-01-00	Cap, Grip Upper
07	3XW-26282-01-00	Cap, Grip Lower
08	98507-05035-00	Screw, Pan Head
09	4TX-26331-40-00	Cable, Starter 1
10	4TX-26334-40-00	Cable, Starter 2
11	3VP-26261-00-00	Connector, Cable
12	4TX-26335-01-00	Cable, Clutch
13	4TX-26292-00-00	Stay
14	95027-06012-00	Bolt, Flange
15	4TX-26280-40-00	Rear View Mirror Assy(left)
16	4TX-26290-40-00	Rear View Mirror Assy(right)



4TX4351-9320



Ref No	Part No	Description
01	4TX-W2587-00-00	Master Cylinder Sub Assy
02	4BH-W0041-00-00	• . Cylinder Kit, Master
03	3YX-25854-00-00	• . Diaphragm, Reservoir
04	4TX-25852-00-00	• . Cap, Reservoir
05	98706-04012-00	• . Screw, Flat Head
06	4BH-83980-00-00	• . Front Stop Switch Assy
07	98506-04014-00	• . Screw, Pan Head
08	92906-04600-00	• . Washer, Plate
09	3YX-25880-00-00	• . Push Rod Comp.
10	95301-06600-00	• . Nut
11	3YX-W0091-02-00	Screw Kit, Master Cylinder
12	3YX-25866-00-00	• . Circlip
13	3YX-25866-10-00	• . Circlip
14	3YX-2583H-00-00	• . Boot
15	3YX-25867-00-00	Bracket, Master Cylinder
16	3YX-83922-00-00	Lever 2
17	3YX-2589F-00-00	Bolt, Lever
18	3YX-25838-00-00	Sleeve, Caliper
19	95606-06100-00	Nut, U
20	95026-06030-00	Bolt, Flange
21	4TX-25872-40-00	Hose, Brake 1
22	1UA-82591-00-00	Band
23	4TX-25874-00-00	Hose, Brake
24	4TX-25871-00-00	Pipe, Brake
25	95024-06025-00	Bolt, Flange
26	90401-10159-00	Bolt, Union
27	90201-10118-00	Washer, Plate
28	4TX-25875-00-00	Holder, Brake Hose 1
29	4TX-26131-10-00	Guide, Cable 1




4TX4351-9330

TDM850(294TX-332G1)


34

STAND, FOOTREST




4TX1351-6340

Ref No	Part No	Description
01	1UA-27410-00-00	Front Footrest Assy (left)
02	46X-27413-00-00	• . Cover, Footrest
03	90157-05079-00	• . Screw, Pan Head
04	1UA-27420-00-00	Front Footrest Assy (right)
05	46X-27413-00-00	• . Cover, Footrest
06	90157-05079-00	• . Screw, Pan Head
07	90109-083E2-00	Bolt
08	90109-083E2-00	Bolt
09	3VD-27442-11-00	Bracket 2
10	3VD-27443-11-00	Bracket 3
11	90179-10247-00	Nut
12	90110-08071-00	Bolt, Hexagon Socket Head
13	1NL-27424-00-00	Damper, Footrest 2
14	90209-08595-00	Washer
15	3VD-27414-00-00	Damper, Footrest
16	3VD-27311-01-00	Stand, Side
17	90109-104E6-00	Bolt
18	90185-10037-00	Nut, Self-locking
19	90506-18224-00	Spring, Tension
20	90506-26225-00	Spring, Tension
21	1TX-27351-00-00	Guide, Side Stand
22	3VD-27315-00-00	Link, Side Stand
23	4BR-27431-00-00	Footrest, Rear 1
24	4BR-27441-00-00	Footrest, Rear 2
25	90501-12743-00	Spring, Compression
26	93501-04011-00	Ball
27	1HX-27437-00-00	Washer, Special
28	95024-06045-00	Bolt, Flange
29	95604-06200-00	Nut, U Flange
30	90387-064H8-00	Collar
31	2GH-27413-00-00	Cover, Footrest
32	90157-05079-00	Screw, Pan Head
33	4TX-27412-00-00	Bracket, Footrest 1
34	4TX-27422-00-00	Bracket, Footrest 2
35	90380-20213-00	Bush, Solid
36	90110-08199-00	Bolt, Hexagon Socket Head
37	36Y-27424-00-00	Damper, Footrest 2
38	90387-104L8-00	Collar
39	90201-10669-00	Washer, Plate
40	3VD-2139X-00-00	Damper




4TX4351-9350

Ref No	Part No	Description
01	3VD-27211-00-00	Pedal, Brake
02	3VD-27212-00-00	Shaft, Brake Pedal
03	22N-18113-00-00	Cover, Shift Pedal
04	90101-06278-00	Bolt
05	92907-06100-00	Washer, Spring
06	90506-20192-00	Spring, Tension
07	4TX-2583V-00-00	Rr. Master Cylinder Assy.
08	3VD-W0042-50-00	• . Cylinder Kit, Master
09	3LN-2582A-00-00	• . Joint
10	3LN-2582F-00-00	• . Hose
11	3LN-2585H-00-00	• . Screw,set
12	92014-08020-00	Bolt, Button Head
13	47X-27222-00-00	Joint
14	95307-08700-00	Nut
15	90240-08013-00	Pin, Clevis
16	90201-08083-00	Washer, Plate
17	91401-20012-00	Pin, Cotter
18	47X-25894-00-00	Tank, Reservoir
19	360-25854-01-00	Diaphragm, Reservoir
20	2GU-25855-00-00	Bush,diaphragm
21	2KF-25852-50-00	Cap, Reservoir
22	90159-06056-00	Screw, With Washer
23	3VD-2582E-10-00	Holder, Reserve Tank
24	95827-06010-00	Bolt, Flange
25	3VD-25895-01-00	Hose, Reservoir
26	90467-14057-00	Clip
27	3VD-25872-51-00	Hose, Brake 1
28	90401-10159-00	Bolt, Union
29	3LC-25885-00-00	Joint
30	90201-10118-00	Washer, Plate




4TX4351-9360

Ref No	Part No	Description
01	4TX-2835G-00-0X	Body, Front Upper 1
01	4TX-2835G-00-5X	Body, Front Upper 1
01	4TX-2835G-00-6X	Body, Front Upper 1
02	99247-00080-00	Emblem, Yamaha
03	4KM-28371-00-00	Damper
04	4TX-21717-00-00	Damper
05	4TX-28381-00-00	Windshield
06	90150-05024-00	Screw, Round Head
07	4TX-2836K-40-00	Panel, Inner 1
08	4TX-28345-00-00	Mole 1
09	4TX-21649-00-00	Damper
10	90179-05523-00	Nut
11	90183-05042-00	Nut, Spring
12	90167-05076-00	Screw, Tapping
13	4TX-28356-40-00	Stay 1
14	90480-14229-00	Grommet
15	90179-06500-00	Nut
16	90480-13426-00	Grommet
17	97707-40010-00	Screw, Tapping
18	90201-052E8-00	Washer, Plate
19	95817-08080-00	Bolt, Flange
20	95817-08035-00	Bolt, Flange
21	4TX-2835U-00-P3	Panel 1
21	4TX-2835U-00-4B	Panel 1
21	4TX-2835U-00-P4	Panel 1
22	4TX-28328-40-00	Emblem
22	4TX-28328-50-00	Emblem
22	4TX-28328-60-00	Emblem
23	4TX-28301-00-00	Graphic Set, Lower Cover 1
23	4TX-28301-10-00	Graphic Set, Lower Cover 1
23	4TX-28301-20-00	Graphic Set, Lower Cover 1
24	30X-2139X-00-00	Damper
25	4TX-2835V-00-P3	Panel 2
25	4TX-2835V-00-4B	Panel 2
25	4TX-2835V-00-P4	Panel 2
26	4TX-28338-40-00	Emblem
26	4TX-28338-50-00	Emblem
26	4TX-28338-60-00	Emblem
27	4TX-28303-00-00	Graphic Set, lower Cover 2
27	4TX-28303-10-00	Graphic Set, lower Cover 2
27	4TX-28303-20-00	Graphic Set, lower Cover 2
28	90338-10132-00	Plug
29	2TV-21639-00-00	Damper 2
30	15A-21717-00-00	Damper
31	90183-05024-00	Nut, Spring
32	90110-05201-00	Bolt, Hexagon Socket Head
33	90179-05523-00	Nut
34	90202-05224-00	Washer, Plate
35	90149-05299-00	Screw
36	90110-05201-00	Bolt, Hexagon Socket Head
37	4TX-2837N-00-00	Grill, Air Intake 1
38	4TX-2837R-00-00	Grill, Air Intake 2
39	97707-50012-00	Screw, Tapping
40	4TX-28321-00-00	Stay 1





Ref No	Part No	Description
41	4TX-28322-00-00	Stay 2
42	90480-01558-00	Grommet
43	95807-06012-00	Bolt, Flange
44	90387-0910H-00	Collar
45	90464-25217-00	Clamp
46	90464-20191-00	Clamp
47	90464-15192-00	Clamp
48	90464-15192-00	Clamp

Ref No	Part No	Description
01	4TX-81410-00-00	Stator Assy
02	4TX-81450-00-00	Rotor Assy
03	98507-06035-00	Screw, Pan Head
04	92907-06600-00	Washer, Plate
05	91317-05016-00	Bolt
06	90465-08380-00	Clamp




4TX1351-6370


Ref No	Part No	Description
01	3GM-83310-00-00	Front Flasher Light Assy 1
02	306-83311-40-00	• . Bulb, Flasher
03	51L-83332-01-00	• . Lens, Flasher
04	97707-40620-00	• . Screw, Tapping
05	3GM-83320-00-00	Front Flasher Light Assy 2
06	306-83311-40-00	• . Bulb, Flasher
07	51L-83342-01-00	• . Lens, Flasher 2
08	97707-40620-00	• . Screw, Tapping
09	95307-12700-00	Nut
10	10V-83365-00-00	Cap
11	3VD-83330-00-00	Rear Flasher Light Assy 1
12	1VU-83332-00-00	• . Lens, Flasher
13	306-83311-40-00	• . Bulb, Flasher
14	97706-40620-00	• . Screw, Tapping
15	3VD-83340-00-00	Flasher Light Assy 2
16	1VU-83342-00-00	• . Lens, Flasher 2
17	306-83311-40-00	• . Bulb, Flasher
18	97706-40620-00	• . Screw, Tapping
19	95307-12600-00	Nut
20	18G-83365-00-00	Cap



4TX1351-6380


Ref No	Part No	Description
01	5DM-83570-20-00	Speedometer Assy
02	4YR-85750-01-00	Fuel Meter Assy
03	5DM-8353E-20-00	Case, Meter Upper
04	4YR-83572-00-00	Case, Speedometer Lower
05	97707-40018-00	Screw, Tapping
06	4YR-8362Y-00-00	Screw, Special
07	4YR-83534-00-00	Socket, Neutral
08	4YR-83517-00-00	Bulb (12v-1.4w T5)
09	4YR-83517-10-00	Bulb
10	4XV-2341B-00-00	Emblem
11	4TX-83526-40-00	Damper 2
12	4TX-83523-40-00	Damper
13	90480-14585-00	Grommet
14	90201-06380-00	Washer, Plate
15	95307-06600-00	Nut
16	4TX-83755-40-00	Sensor, Speed
17	4TX-2517G-00-00	• . Rotor, Sensor
18	90465-14310-00	Clamp





4TX4351-9400

Ref No	Part No	Description
01	4TX-84320-00-00	Lens Assy
04	3GM-84340-40-00	Socket Cord Assy 1
05	3GM-84397-40-00	Cover, Socket
06	3TJ-84351-00-00	Clamp, Cord
07	4TX-84163-00-00	Damper
08	4TX-84359-10-00	Cord, Headlight
09	3GM-84301-00-00	Pilot Light Assy 1
10	3GM-84321-00-00	• Lens Assy
11	3GM-84322-00-00	• Gasket, Lens
12	47G-85353-00-00	• Bulb
13	3GM-84192-10-00	• Screw, Special
14	90167-05025-00	Screw, Tapping
15	4TX-8431R-00-00	Stay, Setting
16	90480-10517-00	Grommet
17	90387-052U5-00	Collar
18	90167-05037-00	Screw, Tapping
19	90201-054K4-00	Washer, Plate
20	3GM-84367-50-00	Damper, Headlight 2




Ref No	Part No	Description
01	4TX-84710-00-00	Taillight Unit Assy
02	31L-84714-00-00	• . Bulb (12v-21/5w)
03	4TX-84733-00-00	• . Lens, Taillight
04	4TX-84723-00-00	• . Gasket, Tail Lens
05	97706-40620-00	• . Screw, Tapping
06	90464-13077-00	Clamp
07	90480-18276-00	Grommet
08	90201-06071-00	Washer, Plate
09	90387-077M3-00	Collar
10	95307-06600-00	Nut
11	4TX-84751-00-00	Bracket, License
12	95027-06014-00	Bolt, Flange
13	90201-06057-00	Washer, Plate
14	95607-06100-00	Nut, U
15	3Y6-85130-02-00	Rear Reflector Assy
16	95707-05500-00	Nut, Flange



4TX1351-6410

Ref No	Part No	Description
01	4TX-83969-40-00	Switch, Handle 5
02	98507-05025-00	• . Screw, Pan Head
03	4TX-83963-40-00	Switch, Handle 3 (right)
04	98507-05045-00	• . Screw, Pan Head
05	437-83936-01-00	Band, Switch Cord
06	3YX-82911-01-00	Holder, Lever 1
07	3YX-83912-00-00	Lever 1
08	3YX-82917-00-00	Switch
09	90123-08096-00	Bolt
10	90179-08148-00	Nut
11	3YX-83945-00-00	Bolt, Lever
12	95607-06100-00	Nut, U
13	98707-03020-00	Screw, Flat Head
14	95027-06020-00	Bolt, Flange



4TX4351-9420